

D) Chest Pad Assembly

A) Base

E) Seat

Model 110 WeldMaster


www.eidosergonomics.com

Assembly Instructions

Tools Needed: 7/16" socket.

Please read all instructions before assembling

Qty of 8 1/4-20 x 3/4 bolts, (4 attached to chest pad and 4 attached to the seat). Qty of 3 PTO pins, (1 attached to the base, 1 attached to chest mount and 1 attached to the back legs).



Step 2: From the back of (A) Base, slide the (D) Chest Pad Assembly into the base and attach PTO pin.





Step 4: Attach the (E) Seat to the base using the enclosed 1/4- 20 x 3/4 hex head bolts. Tighten using a 7/16" socket.

B) Front Leg

Step 5: Place (B) Front leg into (A) Base and attach the PTO pin.

Step 6: Place (C) Back legs into (A) Base and attach the PTO pin.





C)Back Legs



Warranty: Eidos products are covered by a limited warranty for a period of five years from date of purchase.

*Online Product Registration:

Front Leg

http://www.eidosergonomics.com/product-registration.html





Eidos Corporation

4755 N. 48th Street, Lincoln, NE 68504 Telephone: 402-466-1119 FAX (402) 466-2023

E-mail: sales@eidosergonomics.com Web: www.eidosergonomics.com